

1003229 022601




FIG. 1 PRIOR ART

FIG. 2




FIG. 3

FIG. 4




FIG. 5




FIG. 6

10003239 000000

Front End CUI for CPDV version 1.0 written by Trung M. Tran

Cell List

260a sf_cell_name1
260b sf_cell_name2
260c sf_cell_name3
260d sf_cell_name4
260e sf_cell_name5
260f sf_cell_name6
260g sf_cell_name7
260h sf_cell_name8
260i sf_cell_name9
260j sf_cell_name10
260k sf_cell_name11
sf_cell_name12 ~ 260l

260

262a User tmtran
262b Host sr-uauis-02
262c Project CORSAIR
262d Cell Directory /home/tmtran/perlsrc

262

User Inputs

cpdv Mode all 267b
cpdv Options 267c Options Help 267e
☐ Submit DREAM job 267a

267

264

Reload 275 Run 268 Run All 272 Run Block 270 Clear 274 Exit 276 Help 277

266

To start, select the cell(s) from the list (left panel), enter cpdv Mode and cpdv Options (middle right panel), then click on the button associated with your cell selection to invoke cpdv. For more helps, click on Help button.

254

FIG.7




FIG.8